



Instructions & Notes:

- The face of the mailbox should be a minimum of 16 feet from the center line of the roadway and always at least 6 inches off any asphalt edge or shoulder edge.
- If the shoulder of the roadway permits, the mailbox should be placed off the roadway to allow the mail delivery vehicle to get out of the traffic flow for safety.
- The mailbox and its support arm should have a minimum of 42 inches of clear space under it for at least 2 feet back to the post from the face of the mailbox to allow the snow plow wing to pass under the mailbox and its arm.
- The town is NOT responsible for repairing or replacing mailboxes hit from the removal of snow off the roadway. Therefore some care and thought should